


PVC Skeleton Hand

a FORMUFIT PVC Plan





Important information.
Read carefully.
Keep this information for further
reference.

WARNING

Serious or fatal injuries can occur from using power tools when cutting PVC pipe. Be sure to read and understand the instructions that came with your power tools before using them.

PVC cement is a noxious chemical that should be used in a well ventilated area. If you become dizzy, light-headed or disoriented, move to fresh air.

Legal

DISCLAIMER: The information provided within this manual is for informational purposes only. FORMUFIT accepts no responsibility, and is excluded from all liability for damage and/or loss which may be suffered by any other party as a result of using or in connection with such use or loss of use of this information, including but not limited to loss of profit, loss of opportunity, loss of business, indirect damages, incidental damages, special or consequential loss, injury or loss of life.

Additional Information




For additional information on how to cut, prepare and assemble PVC, please review our FORMUFIT PVC Field Manuals available at:

<http://www.formufit.com/guides>


To order fittings, connectors, pipe or accessories for this project, visit FORMUFIT online at:

<http://www.formufit.com>








Tools




or



Fittings

Quantity	Image	Description	Part Number
10x		<u>1-1/4" 45 Degree Elbow</u>	<u>F11445E</u>
7x		<u>1-1/4" Ball End Cap</u>	<u>F114BEC</u>
3x		<u>1-1/4" 90 Degree Elbow</u>	<u>F11490E</u>
2x		<u>1-1/4" 4-Way Tee</u>	<u>F1144WT</u>
1x		<u>1-1/4" 5-Way Cross</u>	<u>F1145WC</u>
1x		<u>1-1/4" Cross</u>	<u>F114CRX</u>
1x		<u>1-1/4" Tee</u>	<u>F114TEE</u>

Pipe



= 1-1/4" (1.660 OD)





= 25 ft.





PVC Pipe Cut Sheet: Click here to download our cut sheets for different pipe lengths (10ft, 5' or 40") to help you cut your PVC pipe efficiently and minimize waste.

Quantity	Icon	Image	Pipe Length
1x	28"		28"
2x	24"		24"
7x	12"		12"
1x	9"		9"
6x	7"		7"
4x	5"		5"
5x	3"		3"
2x	1.5"		1.5"


1





2




3





4


		5"	12"
2x	1x	1x	1x



To assist with final assembly, tag this section as "Thumb"



5

		7"	9"	12"
2x	1x	1x	1x	1x



To assist with final assembly, tag this section as “Little Finger”

6





Build a total of three identical 'fingers'.


In this step. To assist with final assembly, tag each finger as one of the following:


- Ring Finger
- Middle Finger
- Index Finger

7




8

	1.5"	24"
2x	2x	2x





9




To secure the arm into soil or grass:


1. Position the PVC arm where you want it installed.
2. Lay a 2x4 flat across the top of the fittings. This helps spread out the force and avoid damage to the PVC.
3. Using a hammer or mallet, strike the 2x4 to drive the pipe into the ground.
4. Continue until the pipe is set about 6" deep to ensure stability. If inserting at an angle, make sure the two front poles are in at least 6 inches.,



10



11



Rotate each finger into a natural, life-like position. Adjust the thumb separately until it is angled to the desired position.

